

EXPAND SERIAL COMMAND FUNCTIONAL SPECIFICATIONS

DXT10L

Ver.1.00

SANYO Electric Co., Ltd
DI Company
Projector Division

1	Overview	8
2	Serial Interface Specification	8
2.1	Transfer Specification	8
2.2	Connection	8
3	Notes for communication	9
4	Functional Execution Command Table	10
5	Functional Execution Command Table	11
5.1	Image Command Table	11
5.2	PC Control Command Table	11
5.3	Video Control Command Table	11
5.4	Input Control Command Table	11
5.5	Screen Command Table	11
5.6	Lamp Command Table	12
5.7	Sound Command Table	12
5.8	Setting Command Table	12
6	Status Read Command Table	13
6.1	Image Status Read Command Table	13
6.2	PC Status Read Command Table	13
6.3	Video Status Read Command Table	13
6.4	Input Status Read Command Table	14
6.5	Screen Status Read Command Table	14
6.6	Lamp Status Read Command Table	14
6.7	Sound Status Read Command Table	14
6.8	Setting Status Read Command Table	15
6.9	Other Status Read Command Table	15
7	Error Code Table	16
8	Functional Execution Command	16
8.1	Format	16
8.2	Transfer Example	16
8.3	Operation Requirements	17
8.4	Image Command	17
8.4.1	CF_BRIGHT Command	17
8.4.2	CF_CONT Command	17
8.4.3	CF_BBAL Command	18
8.4.4	CF_COLOR Command	18
8.4.5	CF_COLMN Command	18
8.4.6	CF_TINT Command	19
8.4.7	CF_SHARP Command	19
8.4.8	CF_GAMMA Command	19
8.4.9	CF_WBAL- Command	20

8.4.10	CF_COLTEMP Command	20
8.4.11	CF_NZRED Command	20
8.4.12	CF_PROGV Command	21
8.4.13	CF_IMAGE Command	21
8.4.14	CF_IMAGEADJ Command	21
8.4.15	CF_BRTCOLOR Command	22
8.4.16	CF_FILM Command	22
8.5	PC Control Command	23
8.5.1	CF_FSYNC Command	23
8.5.2	CF_TDOTS Command	23
8.5.3	CF_H-POS Command	23
8.5.4	CF_V-POS Command	23
8.6	Video Control Command	24
8.6.1	CF_AVOVSCN Command	24
8.7	Input Control Command	25
8.7.1	CF_INPUT Command	25
8.7.2	CF_SYSTEM Command	25
8.8	Screen Control Command	26
8.8.1	CF_SCREEN Command	26
8.8.2	CF_KEYSTONE Command	26
8.9	Lamp Command	27
8.9.1	CF_LAMPH Command	27
8.9.2	CF_LAMPMODE Command	27
8.9.3	CF_AUTOLAMPCTRL Command	27
8.10	Sound Command	28
8.10.1	CF_VOLUME Command	28
8.10.2	CF_MUTE Command	28
8.11	Setting Command	29
8.11.1	CF_BACKGND Command	29
8.11.2	CF_CEIL Command	29
8.11.3	CF_REAR Command	29
8.11.4	CF_RCSENSOR Command	30
8.11.5	CF_LANG Command	30
8.11.6	CF_ON-STA Command	30
8.11.7	CF_P-MANE Command	31
8.11.8	CF_FANSPEED Command	31
8.11.9	CF_KEYDIS Command	31
8.11.10	CF_FDEFAULT Command	31
8.11.11	CF_PJPINCODE Command	32
8.11.12	CF_TESTPAT Command	32

8.11.13	CF_FILH Command	32
8.11.14	CF_FILTER Command	33
8.11.15	CF_FREEZE Command	33
9	Status Read Command.....	34
9.1	Format	34
9.2	Transfer Example.....	34
9.3	OSD.....	34
9.4	Image Status Read Commands	35
9.4.1	CR_BRIGHT Command.....	35
9.4.2	CR_CONT Command	35
9.4.3	CR_BBAL-R Command.....	35
9.4.4	CR_BBAL-G Command.....	35
9.4.5	CR_BBAL-B Command.....	35
9.4.6	CR_COLOR Command.....	36
9.4.7	CR_COLMN-R Command.....	36
9.4.8	CR_COLMN-G Command	36
9.4.9	CR_COLMN-B Command.....	36
9.4.10	CR_COLMN-Y Command.....	36
9.4.11	CR_COLMN-M Command	37
9.4.12	CR_COLMN-C Command.....	37
9.4.13	CR_TINT Command.....	37
9.4.14	CR_SHARP Command	37
9.4.15	CR_GAMMA Command.....	37
9.4.16	CR_WBAL-R Command	38
9.4.17	CR_WBAL-G Command.....	38
9.4.18	CR_WBAL-B Command	38
9.4.19	CR_COLTEMP Command	38
9.4.20	CR_NZRED Command	38
9.4.21	CR_PROGV Command.....	39
9.4.22	CR_FILM Command	39
9.4.23	CR_IMAGE Command.....	39
9.4.24	CR_BRTCOLOR Command	39
9.5	PC Status Read Commands	40
9.5.1	CR_FSYNC Command	40
9.5.2	CR_TDOTS Command	40
9.5.3	CR_H-POS Command	40
9.5.4	CR_V-POS Command.....	40
9.5.5	CR_SETPCADJ Command.....	41
9.6	Video Status Read Command.....	42
9.6.1	CR_SERSYS Command.....	42

9.6.2	CR_AVOVSCN Command	42
9.7	Input States Read Command	43
9.7.1	CR_INPUT Command	43
9.7.2	CR_SOURCE Command	43
9.7.3	CR_SYSTEM Command	44
9.7.4	CR_SYSLIST Command	44
9.7.5	CR_SRCINP1 Command	44
9.7.6	CR_SRCINP2 Command	45
9.7.7	CR_SRCINP3 Command	45
9.7.8	CR_SRCINP4 Command	45
9.7.9	CR_SRCINP5 Command	45
9.7.10	CR_SRCINP6 Command	45
9.7.11	CR_HMSLOT Command	45
9.7.12	CR_NMSLOT1 Command	46
9.7.13	CR_NMSLOT2 Command	46
9.7.14	CR_NMSLOT3 Command	46
9.7.15	CR_NMSLOT4 Command	46
9.7.16	CR_NMSLOT5 Command	46
9.7.17	CR_NMSLOT6 Command	46
9.7.18	CR_IDSLOT1 Command	47
9.7.19	CR_IDSLOT2 Command	47
9.7.20	CR_IDSLOT3 Command	47
9.7.21	CR_IDSLOT4 Command	47
9.7.22	CR_IDSLOT5 Command	48
9.7.23	CR_IDSLOT6 Command	48
9.8	Screen Status Read Commands	49
9.8.1	CR_SCREEN Command	49
9.8.2	CR_KYSTNMODE Command	49
9.9	Lamp Status Read Commands	50
9.9.1	CR_LAMPREPL Command	50
9.9.2	CR_LAMPH Command	50
9.9.3	CR_LAMPMODE Command	50
9.9.4	CR_AUTOLAMPCTRL Command	51
9.9.5	CR_LAMPSTS Command	51
9.9.6	CR_INFLAMP Command	51
9.9.7	CR_PROJH Command	51
9.9.8	CR_HMLAMP Command	51
9.10	SOUND status Read Commands	52
9.10.1	CR_VOLUME Command	52
9.10.2	CR_MUTE Command	52

9.11	Setting Status Read Commands	53
9.11.1	CR_BACKGND Command	53
9.11.2	CR_CEIL Command	53
9.11.3	CR_REAR Command	53
9.11.4	CR_RCSENSOR Command	53
9.11.5	CR_LANG Command	54
9.11.6	CR_P-MANE Command	54
9.11.7	CR_P-MANETIME Command	54
9.11.8	CR_FANSPEED Command	54
9.11.9	CR_KEYDIS Command	54
9.11.10	CR_SECURITY Command	55
9.11.11	CR_PJLOCKNOW Command	55
9.11.12	CR_PJLOCKMENU Command	55
9.11.13	CR_TESTPAT Command	55
9.11.14	CR_FILH Command	55
9.11.15	CR_FILREPL Command	56
9.11.16	CR_FILTIMER Command	56
9.12	Other Status Read Commands	57
9.12.1	CR_STATUS Command	57
9.12.2	CR_SIGNAL Command	57
9.12.3	CR_VMUTE Command	57
9.12.4	CR_FREEZE Command	57
9.12.5	CR_ALLPFAIL Command	58
9.12.6	CR_HMPFAIL Command	59
9.12.7	CR_PFAIL01 Command	59
9.12.8	CR_PFAIL02 Command	59
9.12.9	CR_PFAIL03 Command	59
9.12.10	CR_PFAIL04 Command	60
9.12.11	CR_PFAIL05 Command	60
9.12.12	CR_PFAIL06 Command	60
9.12.13	CR_PFAIL07 Command	61
9.12.14	CR_PFAIL08 Command	61
9.12.15	CR_PFAIL09 Command	61
9.12.16	CR_PFAIL10 Command	62
9.12.17	CR_PFAIL11 Command	62
9.12.18	CR_PFAIL12 Command	62
9.12.19	CR_PFAIL13 Command	63
9.12.20	CR_PFAIL14 Command	63
9.12.21	CR_PFAIL15 Command	63
9.12.22	CR_PFAIL16 Command	64

9.12.23	CR_PFAIL17 Command	64
9.12.24	CR_PFAIL18 Command	64
9.12.25	CR_PFAIL19 Command	65
9.12.26	CR_TEMPWARN Command	65
9.12.27	CR_TEMPFAIL Command	66
9.12.28	CR_TEMP Command	67

1 Overview

- This Functional Specification defines Network communication for DXT10L.
- Commands are designed for Network communication, but most commands are also available to remote-control a projector through RS-232C from a computer. Therefore, commands are defined as Expand Serial Commands.
- The operation by some commands depends on Input or Source of the projector.

2 Serial Interface Specification

2.1 Transfer Specification


Items	Specification
Synchronous System	Asynchronous
Transmission Speed	4800/9600/19200/38400
Data Length	8 bit
Parity	N/A
Stop Bit	1
Flow Control	N/A

1) Transmission Speed: Initial setting value is 38400.

2) Transmission Speed can be changed in Menu.

2.2 Connection

Use the dedicated serial cable that meets to following specifications for the connection between a computer and the projector.



Connect COM port of the computer to SERIAL PORT IN of the projector.

COM Port (COM1 or COM2) of a computer is specified by the control software of the computer.

3 Notes for communication

3.1 Expand Serial Command is defined as a single command per line that starts with “C” and ends with carriage return (0x0D).

When a projector receives carriage return (0x0D), it starts decoding.

3.2 There are two types of commands; the Functional Execution Command and the Status Read Command.

- Example of Functional Execution Command: “CF_BRIGHT_032” [CR]
- Example of Status Read Command: “CR_BRIGHT” [CR]

3.2.1.1.1 Note) “_” indicates a space


3.3 It clears the information of buffer in the conditions bellow:

- When the projector receives LF (0x0A) or EOF (0x1A).
- When it takes more than one second to receive a single command.

(Until receiving the carriage return after the reception of the first data.)

3.4 The projector processes commands and returns responses within a few ms to 8000 ms after the reception of the command.

When several commands are issued in succession, do not send another command unless the response to the previous command has been returned; need to confirm that the processing of the current command has been completed and returned the response before sending another command.



Note) When the computer sends another command before the previous response has been returned, the projector may not operate properly.

Note) When the current command processing has not been completed, another command process can not be accepted by the projector.

3.4.1 Normally it is less than 1000ms for the completion of receiving a command and returning the response, but it takes more than 1000ms for some Functional Execution Commands (CF commands) as listed below:

Command	Item
CF_IMAGE	Select Image Mode
CF_INPUT	Select Input
CF_SCREEN	Select Screen Size
CF_SYSTEM	Select System
CF_IMAGEADJ	Reset/Store for Image Adjustment

It takes about 8 seconds for the internal initialization after plugging in AC power. During the period cannot process commands. Do not issue any command.

4 Functional Execution Command Table

4.1 Data from a controller to a projector is represented as COMMAND, and data from a projector to a controller in response to the incoming command is represented as RESPONSE.

4.2 [CR]: Carriage Return Code

The command ends with carriage return code.

The response also ends with carriage return code.

4.3 _: Space Code

All space code is indicated by (_).

4.4 %1: Parameter included in command.

When there is more than one parameter, they are represented as %2, %3...

4.5 In this specifications, "Slot" notation is same as "Input" notation. Etc.Slot1=Input1.

5 Functional Execution Command Table

5.1 Image Command Table

Execute command	Item
CF_BRIGHT_%1[CR]	Set value of Brightness
CF_CONT_%1[CR]	Set value of Contrast
CF_BBAL-%1_%2[CR]	Set value of Contrast R,G,B
CF_COLOR_%1[CR]	Set value of Color
CF_COLMN_%1_%2[CR]	Set value of Color Correction
CF_TINT_%1[CR]	Set value of Hue
CF_SHARP_%1[CR]	Set value of Sharpness
CF_GAMMA_%1[CR]	Set value of Gamma Correction
CF_WBAL-R_%1[CR]	Set Brightness Red value of White Balance
CF_WBAL-G_%1[CR]	Set Brightness Green value of White Balance
CF_WBAL-B_%1[CR]	Set Brightness Blue value of White Balance
CF_COLTEMP_%1[CR]	Set level of Color Temperature
CF_NZRED_%1[CR]	Set ON/OFF of Noise Reduction
CF_PROGV_%1[CR]	Set mode of Deinterlace
CF_IMAGE_%1[CR]	Set Image mode Preset
CF_IMAGEADJ_%1[CR]	Set Store/Reset of values in Image Adjustment
CF_BRTCOLOR_%1[CR]	Set value of Brilliant Color
CF_FILM_%1[CR]	Set ON/OFF of Telecine

5.2 PC Control Command Table

Execute command	Item
CF_FSYNC_%1[CR]	Set value of Phase
CF_TDOTS_%1[CR]	Set value of Clock
CF_H-POS_%1[CR]	Set value of Horizontal Position
CF_V-POS_%1[CR]	Set value of Vertical Position

5.3 Video Control Command Table

Execute command	Item
CF_AVOVSCN_%1[CR]	Set value of Overscan

5.4 Input Control Command Table

Execute command	Item
CF_INPUT_%1[CR]	Select Input
CF_SYSTEM_%1[CR]	Select System in Video or S-Video input mode

5.5 Screen Command Table

Execute command	Item
CF_SCREEN_%1[CR]	Select Aspect Ratio.
CF_KEystone_%1[CR]	Set Keystone Correction

5.6 Lamp Command Table

Execute command	Item
CF_LAMPH_%1[CR]	Reset total running time for each lamp
CF_LAMPMODE_%1[CR]	Select lamp mode (Full/Half)
CF_AUTOLAMPCTRL_%1[CR]	Switch dimmer function levels of Normal/Eco

5.7 Sound Command Table

Execute command	Item
CF_VOLUME_%1[CR]	Set value of Volume.
CF_MUTE_%1[CR]	Set ON/OFF of Sound Mute.

5.8 Setting Command Table

Execute command	Item
CF_BACKGND_%1[CR]	Set background image while no signal.
CF_CEIL_%1[CR]	Set ON/OFF of Ceiling
CF_REAR_%1[CR]	Set ON/OFF of Rear
CF_RCSENSOR_%1[CR]	Set Remote sensor On/Off
CF_LANG_%1[CR]	Select language for OSD
CF_ON-STA_%1[CR]	Set ON/OFF of Power ON Start
CF_P-MANE_%1[CR]	Set ON/OFF of Power Management
CF_FANSPEED_%1[CR]	Select Fan Speed
CF_KEYDIS_%1[CR]	Set limitation of RC/KEY control
CF_FDEFAULT_%1[CR]	Return the settings to Factory Default status
CF_PJPINCODE_%1[CR]	Set Security code to release Lock.
CF_TESTPAT_%1[CR]	Set test pattern.
CF_FILH_%1[CR]	Reset Filter Usage Time.
CF_FILTIMER_%1[CR]	Set timing to display alarm of cleaning and exchange filter.
CF_FREEZE_%1[CR]	Set Freeze on.

6 Status Read Command Table

6.1 Image Status Read Command Table

Status read command	Item
CR_BRIGHT [CR]	Get value of Brightness
CR_CONT [CR]	Get value of Contrast
CR_BBAL-%1_%2[CR]	Get value of Contrast R,G,B
CR_COLOR [CR]	Get value of Color
CR_COLMN_%1_%2[CR]	Set value of Color Correction
CR_TINT [CR]	Get value of Tint
CR_SHARP [CR]	Get value of Sharpness
CR_GAMMA [CR]	Get value of Gamma
CR_WBAL-R [CR]	Get Red value of White Balance
CR_WBAL-G [CR]	Get Green value of White Balance
CR_WBAL-B [CR]	Get Blue value of Whit Balance
CR_COLTEMP [CR]	Get value of Color temperature
CR_NZRED [CR]	Get setting status of Noise Reduction
CR_PROGV [CR]	Get setting status of Deinterlace
CR_IMAGE [CR]	Get Selected Image Status
CR_BRTCOLOR_%1[CR]	Set value of Brilliant Color
CR_FILM_%1[CR]	Set ON/OFF of Telecine

6.2 PC Status Read Command Table

Status read command	Item
CR_FSYNC [CR]	Get setting value of Fine Sync.
CR_TDOTS [CR]	Get setting value of Total Dots
CR_H-POS [CR]	Get setting value of Horizontal Position
CR_V-POS [CR]	Get setting value of Vertical Position
CR_SETPCADJ [CR]	Get currently displayed signal

6.3 Video Status Read Command Table

Status read command	Item
CR_SERSYS [CR]	Get currently selected signal.
CR_AVOVSCN [CR]	Get currently value of Overscan.

6.4 Input Status Read Command Table

Status read command	Item
CR_INPUT [CR]	Get selected Input
CR_SOURCE [CR]	Get selected Source
CR_SYSTEM [CR]	Get selected System in Video Input mode
CR_SYSLIST [CR]	Get candidate of the signal system list
CR_SRCINP1 [CR]	Get selected source for Input 1
CR_SRCINP2 [CR]	Get selected source for Input 2
CR_SRCINP3 [CR]	Get selected source for Input 3
CR_SRCINP4 [CR]	Get selected source for Input 4
CR_SRCINP5 [CR]	Get selected source for Input 5
CR_SRCINP6 [CR]	Get selected source for Input 6
CR_HMSLOT [CR]	Get the total number of slots.
CR_NMSLOT1 [CR]	Get selected source for Input 1
CR_NMSLOT2 [CR]	Get selected source for Input 2
CR_NMSLOT3 [CR]	Get selected source for Input 3
CR_NMSLOT4 [CR]	Get selected source for Input 4
CR_NMSLOT5 [CR]	Get selected source for Input 5
CR_NMSLOT6 [CR]	Get selected source for Input 6
CR_IDSLOT1 [CR]	Get selected source for Input 1
CR_IDSLOT2 [CR]	Get selected source for Input 2
CR_IDSLOT3 [CR]	Get selected source for Input 3
CR_IDSLOT4 [CR]	Get selected source for Input 4
CR_IDSLOT5 [CR]	Get selected source for Input 5
CR_IDSLOT6 [CR]	Get selected source for Input 6

6.5 Screen Status Read Command Table

Status read command	Item
CR_SCREEN [CR]	Get selected screen size
CR_KYSTNMODE [CR]	Get Keystone mode

6.6 Lamp Status Read Command Table

Status read command	Item
CR_LAMPREPL [CR]	Get information on Lamp replacement time
CR_LAMPH [CR]	Get total Actuality used time of lamps
CR_LAMPMODE [CR]	Get selected Lamp mode
CR_AUTOLAMPCONTRL[CR]	Get setting status of dimmer function level.
CR_LAMPSTS [CR]	Get Lamp lighting status
CR_INFLAMP [CR]	Get Lamp switching status
CR_PROJH [CR]	Get total running time of projector
CR_HMLAMP [CR]	Get the total number of lamps

6.7 Sound Status Read Command Table

Status read command	Item
CR_VOLUME[CR]	Get value of Volume.
CR_MUTE[CR]	Get setting status of Mute.

6.8 Setting Status Read Command Table

Status read command	Item
CR_BACKGND [CR]	Get setting status of display while no signal
CR_CEIL [CR]	Get setting status of ceiling
CR_REAR [CR]	Get setting status of Rear
CR_RCSENSOR [CR]	Get setting status of rcsensor
CR_LANG [CR]	Get selected language
CR_P-MANE [CR]	Get setting status of Power management
CR_P-MANETIME [CR]	Get value of time when Power management
CR_FANSPEED [CR]	Get selected Fan Control Speed
CR_KEYDIS [CR]	Get setting status of RC/KEY control limitation
CR_SECURITY [CR]	Get setting status of security
CR_PJLOCKKNOW [CR]	Get actual setting status of security
CR_PJLOCKMENU [CR]	Get setting status of security of menu
CR_TESTPAT[CR]	Get setting status of testpattern
CR_FILH[CR]	Get total use time of filter
CR_FILREPL[CR]	Get information to replace filter
CR_FILTIMER[CR]	Get setting status of filter message time

6.9 Other Status Read Command Table

Status read command	Item
CR_STATUS [CR]	Get status of projector.
CR_SIGNAL [CR]	Get status of signal existence.
CR_VMUTE [CR]	Get setting status of No Show.
CR_FREEZE [CR]	Get setting status of Freeze
CR_ALLPFAIL[CR]	Get information on Power Failure
CR_HMPFAIL[CR]	Get total number of Power failure possible to detect
CR_PFAIL01[CR]	Get name of No.01 of error list and get status.
CR_PFAIL02[CR]	Get name of No.02 of error list and get status.
⋮	⋮
⋮	⋮
CR_PFAIL19[CR]	Get name of No.19 of error list and get status.
CR_TEMPWARN [CR]	Get temperature status whether it is close to abnormal level or not.
CR_TEMPFAIL [CR]	Get temperature in abnormal temperature status.
CR_TEMP [CR]	Get temperature status of now.

7 Error Code Table

Error Code	Contents
?	-When the received data which cannot be decoded. -Parameter designation error (wrong digit number, including invalid value, etc.)
000	Normal reception. (This is "Not" error.)
101	Specified function is not available in the selected mode.
102	Specified value is out of range. (Not reflected)
103	Command mismatched to Hardware (The command is for the Optional function which is not implemented)
201	Increased/decreased value is out of range in the item which is specified with numerical parameter or changeable numerical value.

8 Functional Execution Command

8.1 Format

PC issues a command in the format below:

Pattern1: "CF_ Command" [CR]

Pattern2: "CF_ Command_" %1 [CR]

CF_: Header

Command: Text

%1: Parameter (Text)

_: Space (To separate Command and Parameter)

The projector decodes the received command and when it gets ready to receive another command, it returns the Correspondence.

"000" [CR]: (0x06, 0x0D) When the projector receives the Functional Execution Command.

"nnn" [CR]: Except "000", when it cannot execute commands for some specific reason.

Refer to [7. Error Code Table] for detail.

When the projector cannot decode the command, it return "?" [CR].

8.2 Transfer Example

When setting projector's total dots to 1344 by Expand Command.

PC → PJ: "CF_TDOTS_1344" [CR]

PC ← PJ: "000" [CR] ----- Acceptable

8.3 Operation Requirements

Functional Execution Commands are limited in the status below/

(Status Read Commands are available in following status.)

Projector Status	Available Functional Execution Command
In Standby Mode	C00: POWER ON
Count Down in process	C00: POWER ON (Countdown is terminated)
Cooling Down in process	NONE (No Execution)
Cooling Down in process due to abnormal temperature	NONE (No Execution)
In Abnormal Temperature	NONE (No Execution)
Power Failure (For 60 seconds after Power failed.)	NONE (No Execution)
Power Saving Cooling Down in process	NONE (No Execution)
In Power Saving status	C00: POWER ON C01: POWER OFF

Note) The projector returns an appropriate error code when it receives other command in the above status.

8.4 Image Command

8.4.1 CF_BRIGHT Command

Command	"CF_BRIGHT_%1" [CR]	
%1	"000-100" ----- Directly specify setting value of Brightness "UP" ----- Increment setting value of Brightness by 1 "DN" ----- Decrement setting value of Brightness by 1	
Details	Set user controlled value of Brightness. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.2 CF_CONT Command

Command	"CF_CONT_%1" [CR]	
%1	"000-100" ----- Directly specify setting value of Contrast "UP" ----- Increment setting value of Contrast by 1 "DN" ----- Decrement setting value of Contrast by 1	
Details	Set user controlled value of Contrast. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.3 CF_BBAL Command

Command	"CF_BBAL-%1_%2" [CR]	
%1	"R" -----Contrast R "G" -----Contrast G "B" -----Contrast B	
%2	"000-100"----- Directly specify setting value of Contrast "UP"----- Increment setting value of Contrast by 1 "DN"----- Decrement setting value of Contrast by 1	
Details	Set user controlled value of Contrast. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.4 CF_COLOR Command

Command	"CF_COLOR_%1" [CR]	
%1	"000-100"----- Directly specify setting value of Color "UP"----- Increment setting value of Color by 1 "DN"----- Decrement setting value of Color by 1	
Details	Set user controlled value of Color. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.5 CF_COLMN Command

Command	"CF_COLMN_%1_%2" [CR]	
%1	"R" -----Color Correction Red "G" -----Color Correction Green "B" -----Color Correction Blue "Y" -----Color Correction Yellow "M" -----Color Correction Magenta "C" -----Color Correction Cyan	
%2	"000-120"----- Directly specify setting value of Color Correction "UP"----- Increment setting value of Color Correction by 1 "DN"----- Decrement setting value of Color Correction by 1	
Details	Set user controlled value of Color Correction (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.6 CF_TINT Command

Command	"CF_TINT_%1" [CR]	
%1	"000-100"----- Directly specify setting value of Tint "UP"----- Increment setting value of Tint by 1 "DN"----- Decrement setting value of Tint by 1	
Details	Set user controlled value of Tint (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.7 CF_SHARP Command

Command	"CF_SHARP_%1" [CR]	
%1	"000-031" ----- Directly specify setting value of Sharpness. "UP"----- Increment setting value of Sharpness by 1 "DN"----- Decrement setting value of Sharpness by 1	
Details	Set user controlled value of Sharpness. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.8 CF_GAMMA Command

Command	"CF_GAMMA_%1" [CR]	
%1	"000-002" ----- Directly specify setting value of Gamma "UP"----- Increment setting value of Gamma by 1 "DN"----- Decrement setting value of Gamma by 1	
Details	Set user controlled value of Gamma. (Available only in the normal Power ON status) 000 : Dynamic 001 : Natural 002 : Black Detail Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.9 CF_WBAL- Command

Command	"CF_WBAL-%1_%2" [CR]	
%1	"R" ----- RED "G" ----- GREEN "B" ----- BLUE	
%2	"000-100"----- Directly specify value of Color selected in %1 of Brightness. "UP"----- Increment setting value of Color specified in %1 of Brightness by 1 "DN"----- Decrement setting value of Color specified in %1 of Brightness by 1	
Details	Set value of Color specified in %1 of White Balance (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.10 CF_COLTEMP Command

Command	"CF_COLTEMP_%1" [CR]	
%1	"000" – "005" "UP" -----Set Color Temp to UP "DN" -----Set Color Temp to DN	
Details	Set Color Temperature (Available only in the normal Power ON status) 000 : 5000 001 : 6500 002 : 7800 003 : 8500 004 : 9300 005 : 10500 Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.11 CF_NZRED Command

Command	"CF_NZRED_%1" [CR]	
%1	"OFF" ----- Set Noise Reduction to OFF "L1" -----Set Noise Reduction to Low "L2" -----Set Noise Reduction to Medium "L3" -----Set Noise Reduction to High "UP" -----Set Noise Reduction to UP "DN" -----Set Noise Reduction to DN	
Details	Set or Cancel Noise Reduction. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.12 CF_PROGV Command

Command	"CF_PROGV_%1" [CR]	
%1	"OFF" ----- Set Deinterlace to OFF "L1" ----- Set Deinterlace Still "L2" ----- Set Deinterlace to Normal "L3" ----- Set Deinterlace to Movie "UP" ----- Set Deinterlace to UP "DN" ----- Set Deinterlace to DN	
Details	Set or Cancel Deinterlace. (Valid only when it is in the normal Power ON status.) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.13 CF_IMAGE Command

Command	"CF_IMAGE_%1" [CR]	
%1	"STANDPC" -----High-Bright (Image adjustment value is set to High-Bright) "PRESEN" -----Presentation (Fixed value to display graphic image with Presentation) "STANDAV" ----- Video (Fixed value to focus on tone reproduction for video) "CINEMA" -----Movie (Fixed value to focus on tone reproduction for Movie) "REAL" -----Graphic (Fixed value to focus on tone reproduction for Graphic) "SRGB" -----sRGB (Fixed value to focus on tone reproduction for sRGB)	
Details	Select Image mode. (Valid only when it is in the normal Power ON status.) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.14 CF_IMAGEADJ Command

Command	"CF_IMAGEADJ_%1"[CR]	
%1	"RST"----- Reset adjusted value for the Image	
Details	Reset adjusted value for Image. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.15 CF_BRTCOLOR Command

Command	"CF_BRTCOLOR_%1"[CR]	
%1	"0001-0003"----- Directly specify setting value of BrilliantColor. "UP"----- Set Brilliant Color to UP "DN"----- Set Brilliant Color to DN	
Details	Reset or Store adjusted value for Image. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.4.16 CF_FILM Command

Command	"CF_FILM_%1"[CR]	
%1	"OFF"----- Reset adjusted value for the Image "AUTO"----- Set Telecine to 2-2/2-3AUTO "22ON"----- Set Telecine to 2-2 ON "23ON"----- Set Telecine to 2-3 ON "UP"----- Set Telecine to UP "DN"----- Set Telecine to DN	
Details	Reset or Store adjusted value for Image. (Available only in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.6 Video Control Command

8.6.1 CF_AVOVSCN Command

Command	"CF_AVOVSCN_%1" [CR]	
%1	"00-15" ----- Set value of Overscan. "UP" ----- Set value of Overscan UP "DN" ----- Set value of Overscan DN	
Details	Select Slot (Only valid when it is in the normal Power ON status.) This command works the same way as "SLOT" button of the projector and remote control. However, if set by "00-15", value of 00,05,10,15(%) is only available. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.7 Input Control Command

8.7.1 CF_INPUT Command

Command	"CF_INPUT_%1" [CR]	
%1	"1" ----- Select Computer1 "2" ----- Select Computer2 "3" ----- Select Computer3 "4" ----- Select Component "5" ----- Select Video "6" ----- Select S-Video "UP" ----- Select Input UP "DN" ----- Select Input DN	
Details	Select Slot (Only valid when it is in the normal Power ON status.) This command works the same way as "SOURCE" button of the projector and remote control. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.7.2 CF_SYSTEM Command

Command	"CF_SYSTEM_%1" [CR]	
%1	Input is Video	"AUTO" ----- Select MODE 1 "NTSC" ----- Select MODE 2 "PAL" ----- Select MODE 3 "SECAM" ----- Select MODE 4
	Input is S-Video	"AUTO" ----- Select MODE 1 "NTSC" ----- Select MODE 2 "PAL" ----- Select MODE 3 "SECAM" ----- Select MODE 4
Details	Select system of the currently selected Input. (Valid only when in the normal Power ON status.) When selected Input does not meet the requirement for the specified %1, return "101" [CR] and the command is not executed. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.8 Screen Control Command

8.8.1 CF_SCREEN Command

Command	"CF_SCREEN_%1" [CR]	
%1	"FULL" ----- Select 4:3 screen display "WIDE" ----- Select 16:9 screen display "CROP" ----- Select the side-cut size screen display "TRUE" ----- Select True mode "NORMAL" ----- Select Normal mode "UP" ----- Select screen UP "DN" ----- Select screen DN	
Details	Select screen size. (Valid only when in the normal Power ON status.) When selected Slot does not meet the requirement for the specified %1, return "101" [CR] and the command is not executed. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.8.2 CF_KEYSTONE Command

Command	"CF_KEYSTONE_%1" [CR]	
%1	"UP" ----- Correct Keystone distortion to reduce upper part of image "FUP" ----- Correct Keystone distortion to reduce upper part largely "DN" ----- Correct Keystone distortion to reduce lower part of image "FDN" ----- Correct Keystone distortion to reduce lower part largely "LEFT" ----- Correct Keystone distortion to reduce lower part "FLFT" ----- Correct Keystone distortion to reduce lower part largely "RIGHT" ----- Correct Keystone distortion to reduce lower part "FRGT" ----- Correct Keystone distortion to reduce lower part largely "RST" ----- Set Keystone to OFF	
Details	Change the correction level of Keystone distortion. (Valid only when in the normal Power ON status.) When the value reaches the correction limit, the projector accepts the command but does not execute it. Display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.9 Lamp Command

8.9.1 CF_LAMPH Command

Command	"CF_LAMPH_%1" [CR]	
%1	"RSTn" (n=1-2) ----- Reset lamp 1-2 running time	
Details	Reset running time of the lamp specified in "n". (Valid only when it is in the normal Power ON status.) This command works the same way as "Clear Lamp1 or Lamp2 Hours" in Reset menu. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.9.2 CF_LAMPMODE Command

Command	"CF_LAMPMODE_%1" [CR]	
%1	"FULL" ----- Set lamp mode to 2-lamp (FULL) "HALF1" ----- Set lamp mode to lamp1 mode (HALF) "HALF2" ----- Set lamp mode to lamp2 mode (HALF)	
Details	Select Lamp mode. (Valid only when in the normal Power ON status.) The value set by this command is stored in EEPROM and the setting remains effective after the power is turned to ALL OFF status. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.9.3 CF_AUTOLAMPCTRL Command

Command	"CF_AUTOLAMPCTRL_%1" [CR]	
%1	"NORMAL" ----- Set lamp control mode to NORMAL "ECO" ----- Set lamp control mode to ECO	
Details	Select Lamp control mode. (Valid only when in the normal Power ON status.) The value set by this command is stored in EEPROM and the setting remains effective after the power is turned to ALL OFF status. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.10 Sound Command

8.10.1 CF_VOLUME Command

Command	"CF_VOLUME_%1" [CR]	
%1	"000-064" "UP" ----- Set Volume to UP "DN" ----- Set Volume to DN	
Details	Set value of Volume. (Valid only when in the normal Power ON status.) Set Volume Up/Down as same as RC transmitter, and set Volume adjustment directly. Set Volume adjustment, release state sound mute on, as same as RC transmitter. The status set by this command is stored in EEPROM and the setting remains effective after the power is turned to ALL OFF status. Display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.10.2 CF_MUTE Command

Command	"CF_MUTE_%1" [CR]	
%1	"ON" ----- Set Sound Mute ON "OFF" ----- Set Sound Mute OFF	
Details	Set/Cancel Sound Mute. (Valid only when in the normal Power ON status.) The status set by this command is stored in EEPROM and the setting remains effective after the power is turned to ALL OFF status. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.7 CF_P-MANE Command

Command	"CF_P-MANE_%1" [CR]	
%1	"OFF" ----- Set Power Management to OFF "05M" ----- Set Power Management to ON by 5 min. "10M" ----- Set Power Management to ON by 10min. "20M" ----- Set Power Management to ON by 20min. "30M" ----- Set Power Management to ON by 30min.	
Details	Set/Cancel Power Management. (Valid only when in the normal Power ON status.) The status set by this command is stored in EEPROM and the setting remains effective after the power is turned to ALL OFF status. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.8 CF_FANSPEED Command

Command	"CF_FANSPEED_%1" [CR]	
%1	"MAX" ----- Select Maximum speed of Fan Control "NOR" ----- Select Normal speed of Fan Control	
Details	Switch Fan Control Speed. (Valid only when in the normal Power ON status.) The status set by this command is stored in EEPROM and the setting remains effective after the power is turned to ALL OFF status. Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.9 CF_KEYDIS Command

Command	"CF_KEYDIS_%1" [CR]	
%1	"NONE" ----- RC & KEY are valid "KEY" ----- Projector KEY is invalid	
Details	Set the limitation of RC/KEY use (Valid only when in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.10 CF_FDEFAULT Command

Command	"CF_FDEFAULT_%1" [CR]	
%1	"RST"	
Details	Return the settings to Factory Default status (Valid only when in the normal Power ON status) Don't display OSD when projector received command.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.11 CF_PJPINCODE Command

Command	"CF_PJPINCODE_%1" [CR]	
%1	"0000000000-3333333333"	
Details	<p>Set Security Password to release lock. (Valid only when in the normal Power ON status).</p> <p>The input up to ten digits is accepted by the binary number.</p> <p>This command is only valid when PJ PIN CODE password-dialog is displayed to enter PIN code after Power is ON.</p> <p>0=UP 1=Down 2=left 3=right Don't display OSD when projector received command.</p>	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.12 CF_TESTPAT Command

Command	"CF_TESTPAT_%1" [CR]	
%1	<p>"CrossHatch" "Raster(0%)" "Raster(25%)" "Raster(50%)" "Raster(100%)" "Raster Red" "Raster Green" "Raster Blue" "Raster Blue 60" "Gray Raster 10" "Gray Raster 30" "Ramp H" "Ramp V" Display OSD when projector received command.</p>	
Details	Select Testpat and display(Valid only when in the normal Power ON status)	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.13 CF_FILH Command

Command	"CF_FILH_%1" [CR]	
%1	"RST"	
Details	<p>Return the Filter Hours to Factory Default status (Valid only when in the normal Power ON status)</p> <p>Don't display OSD when projector received command.</p>	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.14 CF_FILTERTIMER Command

Command	"CF_FILTERTIMER_%1" [CR]	
%1	"OFF" ----- OFF (No warning display) "100H"----- 100 hours "200H"----- 200 hours "500H"----- 500 hours "1000H"----- 1000 hours Don't display OSD when projector received command.	
Details	Set time when display Filter Message.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

8.11.15 CF_FREEZE Command

Command	"CF_FREEZE_%1" [CR]	
%1	"ON" -----Set Freeze on "OFF" -----Set Freeze off "UP" -----Set Freeze Sequentially(On→Off→On→....) "DN" -----Set Freeze reverse order (Off→On→Off→....) Don't display OSD when projector received command.	
Details	Set/Cancel Freeze function. (Available only in the normal Power ON status) Receiving FREEZE_ON command when the projector is Freeze enabled, Freeze status is kept.	
Correspondence	Acceptable	"000" [CR]
	Unacceptable	"Error Code" [CR]

9 Status Read Command

9.1 Format

- 1) PC issues a command in the format below:

“CR_Command” [CR]

Command: String

- 2) When the projector receives the applicable command, it returns the required information as a data string.

“000_” %1 [CR]

%1: required Information (a data string. Refer to [Basic Status Read Command Table])

- 3) When the received data cannot be decoded, the projector returns “?” **[CR]**

9.2 Transfer Example

Getting total dots of the projector by Expand Serial Commands

PC → PJ: “CR_TDOTS” [CR]

PC ← PJ: “000_%1344” [CR]

9.3 OSD

Don't display OSD when projector received Status Read command.

9.4 Image Status Read Commands

9.4.1 CR_BRIGHT Command

Command	"CR_BRIGHT" [CR]	
Details	Get user controlled value of Brightness	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.2 CR_CONT Command

Command	"CR_CONT" [CR]	
Details	Get user controlled value of Contrast	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.3 CR_BBAL-R Command

Command	"CR_BBAL-R" [CR]	
Details	Get user controlled value of Brightness R	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.4 CR_BBAL-G Command

Command	"CR_BBAL-G" [CR]	
Details	Get user controlled value of Brightness G	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.5 CR_BBAL-B Command

Command	"CR_BBAL-B" [CR]	
Details	Get user controlled value of Brightness B	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.6 CR_COLOR Command

Command	"CR_COLOR" [CR]	
Details	Get user controlled value of Color	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.7 CR_COLMN-R Command

Command	"CR_COLMN-R" [CR]	
Details	Get user controlled value of Color Correction R	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"-60" – "060"
	Unacceptable	"?" [CR]

9.4.8 CR_COLMN-G Command

Command	"CR_COLMN-G" [CR]	
Details	Get user controlled value of Color Correction G	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"-60" – "060"
	Unacceptable	"?" [CR]

9.4.9 CR_COLMN-B Command

Command	"CR_COLMN-B" [CR]	
Details	Get user controlled value of Color Correction B	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"-60" – "060"
	Unacceptable	"?" [CR]

9.4.10 CR_COLMN-Y Command

Command	"CR_COLMN-Y" [CR]	
Details	Get user controlled value of Color Correction Y	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"-60" – "060"
	Unacceptable	"?" [CR]

9.4.11 CR_COLMN-M Command

Command	"CR_COLMN-M" [CR]	
Details	Get user controlled value of Color Correction M	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"-60" – "060"
	Unacceptable	"?" [CR]

9.4.12 CR_COLMN-C Command

Command	"CR_COLMN-C" [CR]	
Details	Get user controlled value of Color Correction C	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"-60" – "060"
	Unacceptable	"?" [CR]

9.4.13 CR_TINT Command

Command	"CR_TINT" CR]	
Details	Get user controlled value of Tint	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"Error Code" [CR] -----When command is invalid in the given condition (such as being selected Slot) "?" [CR] ----- When unknown command is received

9.4.14 CR_SHARP Command

Command	"CR_SHARP" [CR]	
Details	Get user controlled value of Sharpness	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "031"
	Unacceptable	"?" [CR]

9.4.15 CR_GAMMA Command

Command	"CR_GAMMA" [CR]	
Details	Get user controlled value of Gamma 000 : Dynamic 001 : Natural 002 : Black Detail	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "002"
	Unacceptable	"?" [CR]

9.4.16 CR_WBAL-R Command

Command	"CR_WBAL-R" [CR]	
Details	Get user controlled value of White Balance Red	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.17 CR_WBAL-G Command

Command	"CR_WBAL-G" [CR]	
Details	Get user controlled value of White Balance Green	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.18 CR_WBAL-B Command

Command	"CR_WBAL-B" [CR]	
Details	Get user controlled value of White Balance Blue	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "100"
	Unacceptable	"?" [CR]

9.4.19 CR_COLTEMP Command

Command	"CR_COLTEMP" [CR]	
Details	Get Color Temp setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000": 5000 "001": 6500 "002": 7800 "003": 8500 "004": 9300 "005": 10500
	Unacceptable	"?" [CR]

9.4.20 CR_NZRED Command

Command	"CR_NZRED" [CR]	
Details	Get Noise Reduction setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"OFF" -----Noise Reduction OFF "L1" -----Noise Reduction Low "L2" -----Noise Reduction Medium "L3" -----Noise Reduction High
	Unacceptable	"?" [CR]

9.4.21 CR_PROGV Command

Command	"CR_PROGV" [CR]	
Details	Get Progressive scan setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"OFF" ----- Progressive OFF "L1" ----- Progressive Still "L2" ----- Progressive Normal "L3" ----- Progressive Movie
	Unacceptable	"?" [CR]

9.4.22 CR_FILM Command

Command	"CR_FILM" [CR]	
Details	Get Film mode setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"OFF"----- Film mode Off "AUTO"-----Telecine 2-2/2-3AUTO "22ON"----- Telecine 2-2 ON "23ON"----- Telecine 2-3 ON
	Unacceptable	"?" [CR]

9.4.23 CR_IMAGE Command

Command	"CR_IMAGE" [CR]	
Details	Get image setting status.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"STANDPC" ----- High-Bright "PRESEN" ----- Presentation "STANDAV" ----- Video "CINEMA" ----- Movie "REAL" ----- Graphic "SRGB" ----- sRGB
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] -----When unknown command is received

9.4.24 CR_BRTCOLOR Command

Command	"CR_BRTCOLOR" [CR]	
Details	Get setting status of Brilliant Color	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"0001-0008"----- Directly specify setting value of BrilliantColor.
	Unacceptable	"?" [CR]

9.5 PC Status Read Commands

9.5.1 CR_FSYNC Command

Command	"CR_FSYNC" [CR]	
Details	Get value of Fine Sync	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"0000-0063" ----- Directly specify setting value of Phase
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.5.2 CR_TDOTS Command

Command	"CR_TDOTS" [CR]	
Details	Get value of Total Dots	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"nnnn" – "9999" (nnnn = Display Dots + Horizontal Position)
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.5.3 CR_H-POS Command

Command	"CR_H-POS" [CR]	
Details	Get value of Horizontal Position	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"0000" – "nnnn" (nnnn = Total Dots - Display Dots)
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.5.4 CR_V-POS Command

Command	"CR_V-POS" [CR]	
Details	Get value of Vertical Position	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"0000" – "nnnn" (nnnn = Total Line - Display Line)
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.5.5 CR_SETPCADJ Command

Command	"CR_SETPCADJ" [CR]	
Details	Get value of Signal name.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	This command is available only Input is PC-Analog. Get value of Signal name. "640x480"-----VGA1 is input. "1024x768"-----XGA1 is input "1600x1200"-----UXGA1 is input
	Unacceptable	"?" [CR] ----- When unknown command is received

9.6 Video Status Read Command

9.6.1 CR_SERSYS Command

Command	"CR_SERSYS" [CR]	
Details	Get currently selected signal. Value only when Slot is video. (Invalid when Slot is computer)	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"1080i60"----- 1080i 60Hz "1080i50" ----- 1080i 50Hz "1035i" ----- 1035i "720P" ----- 720p "575P" ----- 575p "480P" ----- 480p "575i" ----- 575i (includes composite signal such as PAL) "480i" ----- 480i (includes composite signal such as NTSC) "NO_SIGNAL" ----- There is no signal
	Unacceptable	"?" [CR]

9.6.2 CR_AVOVSCN Command

Command	"CR_AVOVSCN" [CR]	
Details	Get value of Overscan.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"00~15" "UP" "DN"
	Unacceptable	"?" [CR]

9.7 Input States Read Command

9.7.1 CR_INPUT Command

Command	"CR_INPUT" [CR]	
Details	Get Setting of Input number.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"1" ~ "6"
	Unacceptable	"?" [CR]

9.7.2 CR_SOURCE Command

Command	"CR_SOURCE" [CR]	
Details	Get selected Source	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ANALOG" ----- ANALOG RGB is selected "YPBPR" ----- Y/Pb/Pr Slot is selected "YCBCR" ----- Y/Cb/Cr Slot is selected "DIGITAL" ----- DVI Slot is selected "VIDEO" ----- Video Slot is selected "S-VIDEO" ----- S-VIDEO Slot is selected "BLANK" ----- without Source
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.7.3 CR_SYSTEM Command

Command	"CR_SYSTEM" [CR]	
Details	Get selected System	
Correspondence	Acceptable	"000_%1" [CR]
	%1	Slot is PC signal "VGA1" -----VGA1 is selected "VGA2" -----VGA2 is selected : : "XGA1" -----XGA1 is selected : : "1080i" -----1080i is selected "1035i" -----1035i is selected "720p" -----720p is selected "575p" -----575p is selected "480p" -----480p is selected "575i" -----575i is selected "480i" -----480i is selected
	%1	Slot is Video "AUTO" ----- Auto is selected "NTSC" ----- NTSC is selected "NTSC443" ----- NTSC4.43 is selected "PAL" ----- PAL is selected "SECAM" ----- SECAM is selected "PAL-M" ----- PAL-M is selected "PAL-N" ----- PAL-N is selected "1080i60" ----- 1080i60Hz is selected "1080i0" ----- 1080i50Hz is selected "1035i" ----- 1035i is selected "720P" ----- 720p is selected "575P" ----- 575p is selected "480P" ----- 480p is selected "575i" ----- 575i is selected "480i" ----- 480i is selected
	Unacceptable	"Error Code" [CR] ---- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.7.4 CR_SYSLIST Command

Command	"CR_SYSLIST" [CR]	
Details	Get Source of Selected Input	
Correspondence	Acceptable	"000_%1" [CR]
	%1	The same data as CR_SRCINP1
	Unacceptable	"?" [CR]

9.7.5 CR_SRCINP1 Command

Command	"CR_SRCINP1" [CR]	
Details	Get Source of Slot1	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ANALOG" ----- in Computer mode
	Unacceptable	"?" [CR]

9.7.6 CR_SRCINP2 Command

Command	"CR_SRCINP2" [CR]	
Details	Get Source of Slot 2	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ANALOG" ----- in Computer mode "YPBPR" ----- in Y/Pb/Pr mode
	Unacceptable	"?" [CR]

9.7.7 CR_SRCINP3 Command

Command	"CR_SRCINP3" [CR]	
Details	Get Source of Slot 3	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"DIGITAL" ----- in DVI mode
	Unacceptable	"?" [CR]

9.7.8 CR_SRCINP4 Command

Command	"CR_SRCINP4" [CR]	
Details	Get Source of Slot 4	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"YPBPR" ----- in Y/Pb/Pr mode
	Unacceptable	"?" [CR]

9.7.9 CR_SRCINP5 Command

Command	"CR_SRCINP5" [CR]	
Details	Get Source of Slot 5	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"VIDEO" ----- in Video mode
	Unacceptable	"?" [CR]

9.7.10 CR_SRCINP6 Command

Command	"CR_SRCINP6" [CR]	
Details	Get Source of Slot 6	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"S-VIDEO" ----- in S-video mode
	Unacceptable	"?" [CR]

9.7.11 CR_HMSLOT Command

Command	"CR_HMSLOT" [CR]	
Details	Get the total number of Slots	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"006"
	Unacceptable	"?" [CR]

9.7.12 CR_NMSLOT1 Command

Command	"CR_NMSLOT1" [CR]	
Details	Get the board name inserted to Slot 1	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"VGA"
	Unacceptable	"?" [CR]

9.7.13 CR_NMSLOT2 Command

Command	"CR_NMSLOT2" [CR]	
Details	Get the board name inserted to Slot 2	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"5BNC"
	Unacceptable	"?" [CR]

9.7.14 CR_NMSLOT3 Command

Command	"CR_NMSLOT3" [CR]	
Details	Get the board name inserted to Slot 3	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"DVI"
	Unacceptable	"?" [CR]

9.7.15 CR_NMSLOT4 Command

Command	"CR_NMSLOT4" [CR]	
Details	Get the board name inserted to Slot 4	
Correspondence	Acceptable	"5BNC"
	%1	The same data as CR_NMSLOT1
	Unacceptable	"?" [CR]

9.7.16 CR_NMSLOT5 Command

Command	"CR_NMSLOT5" [CR]	
Details	Get the board name inserted to Slot 5	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"VIDEO"
	Unacceptable	"?" [CR]

9.7.17 CR_NMSLOT6 Command

Command	"CR_NMSLOT6" [CR]	
Details	Get the board name inserted to Slot 6	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"VIDEO"
	Unacceptable	"?" [CR]

9.7.18 CR_IDSLOT1 Command

Command	"CR_IDSLOT1" [CR]	
Details	Get ID information on Slot 1. This command is used to recognize the inserted board and specify the valid Slot source.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"00" ----- Video board Valid Slot Source: VIDEO, S-VIDEO "01" ----- D-sub board Valid Slot Source: ANALOG "04" ----- Component board Valid Slot Source: YPBPR "05" ----- DVI board Valid Slot Source: DIGITAL "99" ----- No board inserted
	Unacceptable	"?" [CR]

9.7.19 CR_IDSLOT2 Command

Command	"CR_IDSLOT2" [CR]	
Details	Get ID information on Slot 2. This command is to recognize the inserted slot board and specify the valid Slot source.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	The same as CR_IDSLOT1
	Unacceptable	"?" [CR]

9.7.20 CR_IDSLOT3 Command

Command	"CR_IDSLOT3" [CR]	
Details	Get ID information on Slot 3. This command is to recognize the inserted slot board and specify the valid Slot source.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	The same as CR_IDSLOT1
	Unacceptable	"?" [CR]

9.7.21 CR_IDSLOT4 Command

Command	"CR_IDSLOT4" [CR]	
Details	Get ID information on Slot 4. This command is to recognize the inserted slot board and specify the valid Slot source.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	The same as CR_IDSLOT1
	Unacceptable	"?" [CR]

9.7.22 CR_IDSLOT5 Command

Command	"CR_IDSLOT5" [CR]	
Details	Get ID information on Slot 5. This command is to recognize the inserted slot board and specify the valid Slot source.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	The same as CR_IDSLOT1
	Unacceptable	"?" [CR]

9.7.23 CR_IDSLOT6 Command

Command	"CR_IDSLOT6" [CR]	
Details	Get ID information on Slot 6. This command is to recognize the inserted slot board and specify the valid Slot source.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	The same as CR_IDSLOT1
	Unacceptable	"?" [CR]

9.8 Screen Status Read Commands

9.8.1 CR_SCREEN Command

Command	"CR_SCREEN" [CR]	
Details	Get currently selected screen image size	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"FULL" -----4:3 screen display "WIDE" -----16:9 screen display "CROP"-----the cropping size screen display "TRUE" -----TRUE mode "NORMAL" -----NORMAL mode
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.8.2 CR_KYSTNMODE Command

Command	"CR_KYSTNMODE" [CR]	
Details	Get currently setting of keystone	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"STR"
	Unacceptable	"Error Code" [CR] ----- When the command is invalid due to condition such as Input source "?" [CR] ----- When unknown command is received

9.9 Lamp Status Read Commands

9.9.1 CR_LAMPREPL Command

Command	"CR_LAMPREPL" [CR]	
Details	Get the information of Lamp Replacement time	
Correspondence	Acceptable	"000_%1" [CR]
	%1	<p>"2**" 2 ----- indicates 2 lamps are used in this model. * ----- indicates the status of each lamp in lamp number order. "Y" means the lamp operating time is over the threshold for lamp replacement, and "N" means it has not reached to.</p> <p>e.g. "2NY" ----- This indicates it is 2-lamp system, and Lamp #1 has not been reached to the replacement time while #2 should be replaced.</p>
	Unacceptable	"?" [CR]

9.9.2 CR_LAMPH Command

Command	"CR_LAMPH" [CR]	
Details	Get actual Lamp used time(measure : Hours(h)).	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1, %2	<p>%1 is lamp1 data, %2 is lamp2 dat, %1 and %2 uses 5 digits.</p> <p>e.g. Lamp1 & Lamp2 "00410 00200"[CR] -----Lamp NO.1 = 410[H] Lamp No.2 = 200[H]</p>
	Unacceptable	"?" [CR]

9.9.3 CR_LAMPMODE Command

Command	"CR_LAMPMODE" [CR]	
Details	Get value of Lamp Select	
Correspondence	Acceptable	"000_%1" [CR]
	%1	<p>"FULL" ----- Lamp Select is Dual "HALF1"----- Lamp Select is Lamp1 "HALF2"----- Lamp Select is Lamp2</p>
	Unacceptable	"?" [CR]

9.9.4 CR_AUTOLAMPCTRL Command

Command	"CR_AUTOLAMPCTRL" [CR]	
Details	Get Lamp mode setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"NORMAL" ----- NORMAL is selected. "ECO" ----- ECO is selected.
	Unacceptable	"Error Code" [CR]

9.9.5 CR_LAMPSTS Command

Command	"CR_LAMPSTS" [CR]	
Details	Get the information of Lamp lighting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"2**" The first character indicates 2 lamps are used in this model. The following characters indicate each lamp status in lamp number order as showed below. "1" ----- Lamp is ON "O" ----- Lamp is OFF "X" ----- Lamp Failure e.g. "2IO" ----- This indicates it is 2-lamp system, Lamp #1 is ON, #2 is OFF.
	Unacceptable	"?" [CR]

9.9.6 CR_INFLAMP Command

Command	"CR_INFLAMP" [CR]	
Details	Get Lamp mode switching status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"NML" ----- in Normal status (lamp switching operation is not active.) "CNG" ----- during lamp switching operation
	Unacceptable	"?" [CR]

9.9.7 CR_PROJH Command

Command	"CR_PROJH" [CR]	
Details	Get total running time of projector (in hours)	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"0000000" – "0099999"
	Unacceptable	"?" [CR]

9.9.8 CR_HMLAMP Command

Command	"CR_HMLAMP" [CR]	
Details	Get total lamp number	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"002"
	Unacceptable	"?" [CR]

9.10 SOUND status Read Commands**9.10.1 CR_VOLUME Command**

Command	"CR_VOLUME" [CR]	
Details	Get value of volume setting	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "064"
	Unacceptable	"?" [CR]

9.10.2 CR_MUTE Command

Command	"CR_MUTE" [CR]	
Details	Get setting status of MUTE	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" ----- Sound mute on "OFF" ----- Sound mute off
	Unacceptable	"?" [CR]

9.11 Setting Status Read Commands

9.11.1 CR_BACKGND Command

Command	"CR_BACKGND" [CR]	
Details	Get Background setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"BLUE" ----- Blue Back is set to on. "BLACK" ----- Black Back is set to on. "USER" ----- Logo is set to on.
	Unacceptable	"?" [CR]

9.11.2 CR_CEIL Command

Command	"CR_CEIL" [CR]	
Details	Get Ceiling setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" -----CeilingRear or CeilingFront is set to ON. "OFF" ----- Desktop Front or Desktop Rear is set to ON.
	Unacceptable	"?" [CR]

9.11.3 CR_REAR Command

Command	"CR_REAR" [CR]	
Details	Get Rear setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" -----Ceiling Rear or Desktop Rear is set to on. "OFF" -----Desktop Front or Ceiling Front is set to on.
	Unacceptable	"?" [CR]

9.11.4 CR_RCSENSOR Command

Command	"CR_RCSENSOR" [CR]	
Details	Get Remote sensor setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"BOTH" -----Front /Back is set to ON. "FRONT" -----Front is set to ON. "BACK" -----Back is set to ON.
	Unacceptable	"?" [CR]

9.11.5 CR_LANG Command

Command	"CR_LANG" [CR]	
Details	Get selected language	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ENG" ----- English is selected "DEU" ----- German is selected "FRA" ----- French is selected "ITA" ----- Italian is selected "ESP" ----- Spanish is selected "SVE" ----- Swedish is selected "CHI" ----- Chinese is selected "JPN" ----- Japanese is selected
	Unacceptable	"?" [CR]

9.11.6 CR_P-MANE Command

Command	"CR_P-MANE" [CR]	
Details	Get Power management setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"OFF" ----- Power Management is set to OFF. "SHUTDOWN" ----- Power Management is available.
	Unacceptable	"?" [CR]

9.11.7 CR_P-MANETIME Command

Command	"CR_P-MANETIME" [CR]	
Details	Get value of Power management time.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "030"(Only available value)
	Unacceptable	"?" [CR]

9.11.8 CR_FANSPEED Command

Command	"CR_FANSPEED" [CR]	
Details	Get currently selected Fan Control Speed.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"MAX" ----- High speed of Fan Control is selected "NOR" ----- Fan Control Auto is selected
	Unacceptable	"?" [CR]

9.11.9 CR_KEYDIS Command

Command	"CR_KEYDIS" [CR]	
Details	Get setting status of RC/KEY use limitation (valid or invalid)	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"NONE" ----- RC & KEY are valid "KEY" ----- KEY is invalid
	Unacceptable	"?" [CR]

9.11.10 CR_SECURITY Command

Command	"CR_SECURITY" [CR]	
Details	Get setting status of Security setting.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" ----- Pin code is Locked. "OFF" ----- Pin code is Free.
	Unacceptable	"?" [CR]

9.11.11 CR_PJLOCKNOW Command

Command	"CR_PJLOCKNOW" [CR]	
Details	Get setting status of PJ Lock on now	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"LOCK" ----- Security is on.Menu is on,and Password is not inputed,actually Locked. "FREE" ----- Security is Off.Menu is off ,or Password was inputed,Lock released.
	Unacceptable	"?" [CR]

9.11.12 CR_PJLOCKMENU Command

Command	"CR_PJLOCKMENU" [CR]	
Details	Get setting status of Security on menu.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" ----- Security is on in menu. "OFF" ----- Security is off in menu.
	Unacceptable	"?" [CR]

9.11.13 CR_TESTPAT Command

Command	"CR_TESTPAT" [CR]	
Details	Get setting status of Test pattern.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"CrossHatch" "Raster1" "Raster2" "Raster3" "Raster4" "Raster5" "Raster6" "Raster7" "Raster8" "Raster9" "Raster10" "RampH" "RampV" "OFF"
	Unacceptable	"?" [CR]

9.11.14 CR_FILH Command

Command	"CR_FILH" [CR]	
Details	Get value of time filter used.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"0000" – "99999"
	Unacceptable	"?" [CR]

9.11.15 CR_FILREPL Command

Command	"CR_FILREPL" [CR]	
Details	Get setting status of time to change filter	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"1Y"-----Filter Exchange time is over value of Filter Message. "1N"-----Filter Exchange time is not over value of Filter Message.
	Unacceptable	"?" [CR]

9.11.16 CR_FILTIMER Command

Command	"CR_FILTIMER" [CR]	
Details	Get setting status of Filter Message.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"OFF" -----Off "100" ----- Display message by 100h used. "300" ----- Display message by 300h used. "500" ----- Display message by 500h used.
	Unacceptable	"?" [CR]

9.12 Other Status Read Commands

9.12.1 CR_STATUS Command

Command	"CR_STATUS" [CR]	
Details	Get status of Projector. This command is same as "CR0", except it has an error code.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"00" = Power on "80" = Standby "40" = Power up Countdown "20" = Cooling "10" = Power Error "28" = Temperature Error cooling "88" = Standby after Temperature Error cooling "02" = Cannot Receive RS232C Commands "24" = Power Management Cooling "21" = Cooling after Lamp Error "81" = Standby after Lamp Error
	Unacceptable	"?" [CR]

9.12.2 CR_SIGNAL Command

Command	"CR_SIGNAL" [CR]	
Details	Get status if there is any signal or not	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" ----- There is signal "OFF" ----- There is no signal
	Unacceptable	"?" [CR]

9.12.3 CR_VMUTE Command

Command	"CR_VMUTE" [CR]	
Details	Get No Show setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" ----- No Show is set to ON. "OFF" ----- No Show is set to OFF.
	Unacceptable	"?" [CR]

9.12.4 CR_FREEZE Command

Command	"CR_FREEZE" [CR]	
Details	Get Freeze setting status	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"ON" ----- Freeze is set to ON. "OFF" ----- Freeze is set to OFF.
	Unacceptable	"?" [CR]

9.12.5 CR_ALLPFAIL Command

Command	"CR_ALLPFAIL" [CR]	
Details	Get all information and status of power fail. It returns it bringing "CR_PFAIL01" "CR - PFAIL50" together. Max Length of bytes is 1200bytes content 24bytes x 50.	
Correspondence	Acceptable	<p>"000_%1_%2" [CR] "000_%3_%4" [CR] "000_%5_%6" [CR] : "000_%97_%98" [CR] "000_%99_%100" [CR]</p> <p>The above-mentioned 50 blocks transmission collectively If content is less 50 blocks, transmission until availableness. It depends on specification of DXT10 projector.</p>
	%1 ~%100	<p>%1, %3,, %99 (odd number) ---Name of Failure status(16bytes fixed length)</p> <p>*Status notation</p> <p>1)Power error ====>Power.err 2)Fan error ====>Fan.err 3) FPGA error ====>FPGA.err 4)Formatter error ====>Formatter.err 5)A foreign object sensor error ====>foreignobj.sens 6)Temperature error(Bimetal) ====>Temp.Bimetal 7)Temperature error(Sensor) ====>Temp.Sensor 8)High temperature due to dust pile-up ====>High-temp.dust 9)Lamp cover error ====>Lampcover.err 10)Lamp(or Lamp1) error ====>Lamp1.err 11)Lamp(or Lamp1) has reached its end of life ====>Lamp1.endof.life 12)Lamp(or Lamp1) has been used beyond its limit ====>Lamp.over.limit 13)Lamp(or Lamp1) housing error ====>Lamp1.housing 14)Lamp(or Lamp1) data error ====>Lamp1.data.err 15)Lamp2 has reached its end of life ====>Lamp2.endof.life 16)Lamp2 has been used beyond its limit ====>Lamp2.over.limit 17)Lamp2 housing error ====>Lamp2.housing 18)Lamp2 data error ====>Lamp2.data.err 19)Lamp2 error ====>Lamp2.err</p> <p>%2, %4,, %100 (even number) ---Status of Failure accrual (2bytes fixed length) Failure accrual : "NG" Not failure : "OK"</p>
	Unacceptable	"error code" [CR] Confirm P18

9.12.6 CR_HMPFAIL Command

Command	"CR_HMPFAIL [CR]	
Details	Get total number of Power failure possible to detect	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"000" – "050" DXT10 reply "019"
	Unacceptable	"error code" [CR] Confirm P18

9.12.7 CR_PFAIL01 Command

Command	"CR_PFAIL01" [CR]	
Details	Get name of No.01 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.8 CR_PFAIL02 Command

Command	"CR_PFAIL02" [CR]	
Details	Get name of No.02 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.9 CR_PFAIL03 Command

Command	"CR_PFAIL03" [CR]	
Details	Get name of No.03 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.10 CR_PFAIL04 Command

Command	"CR_PFAIL04" [CR]	
Details	Get name of No.04 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.11 CR_PFAIL05 Command

Command	"CR_PFAIL05" [CR]	
Details	Get name of No.05 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.12 CR_PFAIL06 Command

Command	"CR_PFAIL06" [CR]	
Details	Get name of No.06 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.13 CR_PFAIL07 Command

Command	"CR_PFAIL07" [CR]	
Details	Get name of No.07 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.14 CR_PFAIL08 Command

Command	"CR_PFAIL08" [CR]	
Details	Get name of No.08 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.15 CR_PFAIL09 Command

Command	"CR_PFAIL09" [CR]	
Details	Get name of No.09 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.16 CR_PFAIL10 Command

Command	"CR_PFAIL10" [CR]	
Details	Get name of No.10 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.17 CR_PFAIL11 Command

Command	"CR_PFAIL11" [CR]	
Details	Get name of No.11 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.18 CR_PFAIL12 Command

Command	"CR_PFAIL12" [CR]	
Details	Get name of No.12 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.19 CR_PFAIL13 Command

Command	"CR_PFAIL13" [CR]	
Details	Get name of No.13 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.20 CR_PFAIL14 Command

Command	"CR_PFAIL14" [CR]	
Details	Get name of No.14 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.21 CR_PFAIL15 Command

Command	"CR_PFAIL15" [CR]	
Details	Get name of No.15 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.22 CR_PFAIL16 Command

Command	"CR_PFAIL16" [CR]	
Details	Get name of No.16 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.23 CR_PFAIL17 Command

Command	"CR_PFAIL17" [CR]	
Details	Get name of No.17 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.24 CR_PFAIL18 Command

Command	"CR_PFAIL18" [CR]	
Details	Get name of No.18 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.25 CR_PFAIL19 Command

Command	"CR_PFAIL19" [CR]	
Details	Get name of No.19 of error list and get status.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2	%1 = name of Power failure status(16bytes fixed length) %2 = status of failure accrual(2bytes fixed length) Failure accrual : "NG" Not failure : "OK" If item is invalid, transmission "NOTHING" e.g. "000 NOTHING OK" [CR]
	Unacceptable	"?" [CR]

9.12.26 CR_TEMPWARN Command

Command	"CR_TEMPWARN" [CR]	
Details	Get the information about the temperature inside the projector (close to the abnormal or in the abnormal status/in the safe temperature level/abnormal status is not detected). It is possible to get the information about more than one sensor all at once if it is applicable.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	"* _*" <p>Sensor 1 data comes first, and then one space, after that sensor 2 data is followed. Each data is as below: "W"--- in or close to the abnormal temp. (Warning Temp.) "S"--- in the safe level of temperature (Safe Temp.) "N"--- the given sensor does not detect abnormal temp.</p> <p>e.g. "S_W" [CR] indicates that the temperature detected at Sensor 1 is in the safe level while Sensor 2 in the abnormal temperature.</p>
	Unacceptable	"?" [CR]

9.12.27 CR_TEMPFAIL Command

Command	"CR_TEMPFAIL" [CR]	
Details	Get the temperature inside the projector when the abnormal status occurs. It is possible to get the temperatures for more than one sensor all at once if it is applicable.	
Correspondence	Acceptable	"000_%1" [CR]
	%1	<p>e.g. "_31.5F"[CR] _ indicates a space. When the temperature goes under 0, the first character is "-", not a space, as in "-05.5F". With more than one temperature sensors installed, projector returns the Correspondences for each sensor in a row.</p> <p>e.g. "_31.5F_35.2S" [CR] The first data indicates sensor 1 data, then one space, and sensor 2 data is followed. Last character in each data indicates the sensor's status. In the abnormal temperature ----- "F" In the safe level of temperature ----- "S" Neither in or close to the abnormal temp. ----- "N"</p> <p>The second example above indicates that the temperature detected by sensor 1 is 31.5 which means in the abnormal temperature, and at sensor 2 is 32.5 degrees which is in the safe temperature.</p> <p>When the abnormal temperature status is not occurred the data should be "_00.0S". When the projector is reset, "_00.0S" is set. Every time abnormal temperature status is detected, it renews the data and returns it. It only returns the renewed data of the latest abnormal temperature and the previous data is cleared.</p>
	Unacceptable	"?" [CR]

9.12.28 CR_TEMP Command

Command	"CR_TEMP" [CR]	
Details	Get the information about the temperature inside the projector (close to the abnormal or in the abnormal status/in the safe temperature level/abnormal status is not detected). It is possible to get the information about more than one sensor all at once if it is applicable.	
Correspondence	Acceptable	"000_%1_%2" [CR]
	%1,%2,%3	<p>%1=Temperature of sensor1 %2=Temperature of sensor2</p> <p>%1, %2-----fixed 6 digits. Between %1 and %2 is space 1 character.</p> <p>"_31.5 F"</p> <p>"_" means a space. if temperature becomes -, the first digit become "-" from "_". Etc. "-05.5F"</p> <p>Last character in each data indicates the sensor's status. "F"... In the abnormal temperature. "W"... It is near abnormal temperature. Temperature in which it warns of danger. "S"... It is far from abnormal temperature.(When it is safe.) "N"... Temperature sensor of correspondence is not detection temperature warning. "E"... Temperature sensor cannot return the data.</p> <p>If temperature sensor is equipped with two or more pieces, returns data continues. Etc. "_31.5F_35.2S"[CR] There is data of temperature sensor 1 in the head, and space 1 digit, and the following data of temperature sensor 2 continues. In the above-mentioned example, Temperature sensor 1 is Temp warning by 31.5. Temperature sensor 2 is not abnormal by 35.2. If hardware is in some abnormalities, cannot return the temperature data, return data what last digit is "E" like "_00.0E". There is a situation when depending on the model. When stand-by, and tens of seconds after Power-On, temperature rises by residual heat of Lamp Ballast, becomes abnormal temperature. Therefore, when in standby and tens of seconds after Power-On, Projector doesn't process temp warning, but temperature data become "_----N" in this case.</p>
	Unacceptable	"?" [CR]