

HDD reading software.
VA-SW300 Version 2.0.5

The “**VA-SW300**” HDD reading Software (hereinafter referred to as the “**Software**”) is reading software for HDD recorded in following DVR.

<DVR>

- DSR-3000(P)
- DSR-300(P)
- DSR-3016(P),DSR-3009(P)
- DSR-3506(P)
- DSR-3716(P,PA),DSR-3709(P,PA),DSR-3706(PA)

The software operating environment is as follows.

<VA-SW 300 Recommended System Requirements>

OS	Windows 2000 or Windows XP
CPU	Intel Pentium 4 2.0 G Hz or faster
RAM	256 MB DDR-SDRAM
CHIPSET	Intel 845 or higher chipsets
VIDEO	Ati Radeon 9200se 128 mb or Nvidia Geforce 5200 128 bit 128 mb graphics adapter
MONITER	The program must run at 1024x768 screen resolution and 32 bit color depth.
HDD	Minimum 150 mb hard disk space
OTHERS	Directx 9.0c MPEG4 Codec (Program will automatically setup at first start if not installed) MJPEG Codec (Program will automatically setup at first start if not installed)

ATTENTION : FOR DISKS HIGHER THAN 137 GB YOU MUST USE ULTRA-ATA RAID CARDS AND YOUR MAINBOARD MUST SUPPORT THAT HARD DISKS.

This section will deal firstly with the procedures for setting up and using the “VA-SW300” HDD reading software. All users should follow the procedures given here to ensure that initial settings are carried out correctly.

<SETUP>

1. Set the Mobile Rack into the computer.

Check the operating environment and set the IDE Mobile Rack(RH-32) of Lian Li Industrial Co.,Ltd into the computer.

The setting method refers to instructions of the Moblie Rack(RH-32).


Note:Because Mobile Rack mentioned above is used in DSR-300, we recommend that you use the same type for your PC.

2. Install this software into the computer.

Run "vasw300.msi",then the installer will advise you.

When the “Installation completed”message is displayed, click “Finish”.

Installation will then be complete, and this Software will appear under [Programs] in the Start menu. If you selected a shortcut icon to be created, a shortcut icon for the software will also appear on the desktop.



<Uninstalling the software>

To uninstall (delete) this software, [Add or Remove Programs] in the Control Panel, select [VASW300] and then uninstall it.

Some files that were created previously may still remain even after the software has been uninstalled. If this is the case, delete the installation folder (initial setting: C:\ProgramFiles\Sanyosecurity\VASW300).

3. Start the software.

Double-click the shortcut icon on the Desktop to run the software. If the codec files is not installed, Program will automatically setup the codecs needed at first start.

For more details, please refer to "VA-SW300.pdf".